

CAD-DRAWING
 THIS DRAWING WAS CREATED ON A COMPUTER AIDED DESIGN (CAD) SYSTEM. TO INSURE THE INTEGRITY OF THE DATA BASE, ALL CHANGES/REVISIONS MUST BE MADE ON THE CAD SYSTEM.

REVISION	DATE
A	02/16/16

TOOLS REQUIRED:

-  FLAT SCREWDRIVER
-  PHILLIPS SCREWDRIVER
-  PRY BAR
-  ADJUSTABLE PLIERS
-  RUBBER Mallet
-  UTILITY KNIFE
-  PUTTY KNIFE
-  PERSONAL PROTECTIVE EQUIPMENT (PPE)

PROCEDURE:

- 1) REMOVE THE TWO RACEWAY COVERS FROM THE BOTTOM OF THE PANEL.
- 2) UNSCREW THE TWO GLIDES FROM THE BOTTOM OF THE PANEL.
- 3) DRILL OUT THE RIVETS FROM THE BOTTOM PAN.
- 4) UNCLIP AND REMOVE THE TRAC-PAC ELECTRICAL ASSEMBLY.
- 5) REMOVE SCREWS FROM CAST ALUMINUM LEGS AND SCREWS FROM THE TOP PAN.
- 6) REMOVE THE FABRIC FROM PANEL.
- 7) REMOVE WELT CORD FROM PANEL.
- 8) REMOVE THE INSULATION BLANKET.
- 9) REMOVE CENTER CORE BY APPLYING PRESSURE TO THE CENTER OF THE CORE.

GENERAL NOTES:

- 1) DISASSEMBLY TIME 25-30 MINUTES
- 2) THIS PROCEDURE ASSUMES BASIC FAMILIARITY WITH HAND TOOLS AND FURNITURE TERMINOLOGY: NO SPECIALIZED TRAINING IS REQUIRED.
- 3) ALL MATERIAL REMOVED AND DISASSEMBLED SHALL BE SORTED AND SEGREGATED WITH LIKE MATERIALS AND DISPOSED OF OR RECYCLED ACCORDING TO RECYCLING AVAILABILITY OR WASTE ACCEPTANCE.
- 4) FOR ITEMS TO BE RECYCLED, REFER TO CALPIA WEBSITE AT WWW.CALPIA.CA.GOV.

MATERIAL TYPE:

- ① STEEL
- ② ALUMINUM
- ③ FABRIC
- ④ PLASTIC
- ⑤ GLASS
- ⑥ FIBERGLASS
- ⑦ FIBERBOARD
- ⑧ WOOD

CALPIA
 STATE OF CALIFORNIA, PRISON INDUSTRY AUTHORITY
 560 EAST NATOMA STREET, FOLSOM, CALIFORNIA, 95630

CENTURY SYSTEMS
 DIASSEMBLY INSTRUCTIONS AND RECYCLING CONTENT
 PANEL

DRAWN BY: D. SPIVEY	DRAWN DATE: 02/16/16	SIZE: D	SCALE: NTS	DWG NO.: 6700-DR
---------------------	----------------------	---------	------------	------------------

